



NOTES:

- 1- Jumper Pin 8 to Pin 9 on plug.
- 2- Because of case mounting size restrictions, only small K-2 elements can be plugged into the SD-1 if the elements must be plugged into their sockets.
- 3- Reset is accomplished by pushing the PTT switch (transmitting) or by turning the unit off, then back on.
- 4- Mount the unit with 4 squares of double backed tape.



Communications Specialists
 426 W. Taft Ave., Orange, CA 92667
 (714) 998-3021 (California) / (800) 854-0547