



NOTES: J08 = CTCSS
 J09 = CTCSS Accessory

Molex 22-01-212 connector will mate to connector in Concept.
 (2) needed, one for J09 & one for J08. Connectors not supplied.

SPECIAL NOTICE

WHEN MOUNTING THE TS-32 WITH A 90 DEGREE ANGLE BRACKET AGAINST THE PCB, BE SURE TO USE THE TWO FIBER SPACERS PROVIDED BETWEEN ANGLE BRACKET AND PCB. IF THIS IS NOT DONE, THE BRACKET WILL SHORT OUT FOILS ON THE PCB.....



Communications Specialists

426 W. Taft Ave., Orange, CA 92667
 (714) 998-3021 (California) / (800) 854-0547