



NOTES: Tone-Squelch model.

1. Place jumper on RX board from junction of R-140 and C-126 to open side of C-132.
2. Remove Yellow wire from RX board to SW-301 and connect to ground on volume control.
3. Remove Blue wire from SW-301 to R-140.