



JU-1 (in)
 JU-2 (out)

NOTE: If exchanging TS-32 for factory channel guard in TPL, use P601 sesignations shown below with no other modifications to radio required...

APPLICATION PARTS
 (not supplied)

- 1- varicap kit
- 1- coupling capacitor (20 to 100pf) (factory does not supply)
- 1- set wires & hardware

SPECIAL NOTICE

WHEN MOUNTING THE TS-32 WITH A 90 DEGREE ANGLE BRACKET AGAINST THE PCB, BE SURE TO USE THE TWO FIBER SPACERS PROVIDED BETWEEN ANGLE BRACKET AND PCB. IF THIS IS NOT DONE, THE BRACKET WILL SHORT OUT FOILS ON THE PCB.....