



1. Change Black wire in mike cord from Pin 4 to Pin 5 in mike plug.
2. Unsolder Black wire from mike hanger in mike case and hook to Red lead coming from SS-32SMP-B (+12vdc).
3. Hook Black SS-32SMP-B lead to mike low (ground).
4. Hook Yellow SS-32SMP-B lead to mike high in series with 1 meg 1/8w resistor.
5. Set tone level; to + or - .5kc to set tone level to an almost inaudible level to catch those abusers on the frequency. A frequency counter hooked to the control station speaker leads will read out which transmitter has been keyed.
6. Tape unit and install between mike cartridge and top of mike case.



Communications Specialists, Inc.

426 W. Taft Ave., Orange, CA 92665-4296
(714) 998-3021 (California), (800) 854-0547