



NOTES:

1. Add 1" violet jumper wire between J202 Pin 8 and Pin 9
2. All leads to J202 and J201 are 3" long
3. Be sure to orient plugs properly
4. Make certain that the voltage regulator VR-1 is jumpered out