

FOR USE WITH: MOTOROLA MAXTRAC APPROVAL DATE: 21NOV97S BY: RTS

DECODE UNIT

## CONNECTIONS

RADIO

(3) (+) SUPPLY INPUT **RED** J6-1 9.6V (-) SUPPLY INPUT **GND** (9) BLACK J6-11 (11)**CALL LAMP #2 BLUE** J6-11 **GND JUNCTION OF R570 AND C567 (1) ALERT TONE** WHT/BLU (12)DTMF SIGNAL INPUT GREEN RXA (13)TRANSPOND TONE WHT/GRN JUNCTION OF R651 AND Q651 **VIOLET JUNCTION OF Q509 AND C515 (2)** CALL LAMP #1 (10)TRANSPOND PTT/SET **BLK/YEL** J8-11 PTT **BROWN (7)** MONITOR/RESET J8-13 HOOK **(4) DECODE LATCH** WHT/ORG **JUNCTION OF Q551 AND R566** DECODE MOMENTARY **BLK/ORG USE FOR HORN HONK** (5) (8) PRIMARY PROGRAM **BLK/BRN** N/C **(2)** SECONDARY PROGRAM VIOLET N/C

THIS IS A RECOMMENDED INSTALLATION PROCEDURE FOR SELECTONE EQUIPMENT BASED ON THE BEST INFORMATION AVAILABLE TO US AT THE TIME OF PUBLICATION. SELECTONE ASSUMES NO RESPONSIBILITY FOR THE ACCURACY OF THE INFORMATION OR THE DAMAGE TO EQUIPMENT RESULTING FROM THE USE OF THIS PROCEDURE SELECTONE INC. • 3501 BREAKWATER AVE. HAYWARD, CA. 94545-1610 • (510) 781-0376

(800) 227-0376

• FAX (510) 781-5454 •

E-Mail admin@selectone.com