

DECODE UNIT

CONNECTIONS

RADIO

(3)	(+) SUPPLY INPUT	RED	J6-1	9.6V
(9)	(-) SUPPLY INPUT	BLACK	J6-11	GND
(11)	CALL LAMP #2	BLUE	J6-11	GND
(1)	ALERT TONE	WHTBLU	JUNCTION OF R570 AND C567	
(12)	DTMF SIGNAL INPUT	GREEN	RXA	
(13)	TRANSPOND TONE	WHT/GRN	JUNCTION	OF R651 AND Q651
(2)	CALL LAMP #1	VIOLET	JUNCTION OF Q501 AND C503	
(10)	TRANSPOND PTT/SET	BLK/YEL	J8-13	PTT
(7)	MONITOR/RESET	BROWN	J8-15	ноок
(4)	DECODE LATCH	WHT/ORG	JUNCTION OF Q551 AND C563	
(5)	DECODE MOMENTARY	BLK/ORG	USE FOR HORN HONK	
(8)	PRIMARY PROGRAM	BLK/BRN	N/C	
(6)	SECONDARY PROGRAM	YELLOW	N/C	

THIS IS A RECOMMENDED INSTALLATION PROCEDURE FOR SELECTONE EQUIPMENT BASED ON THE BEST INFORMATION AVAILABLE TO US AT THE TIME OF PUBLICATION. SELECTONE ASSUMES NO RESPONSIBILITY FOR THE ACCURACY OF THE INFORMATION OR THE DAMAGE TO EQUIPMENT RESULTING FROM THE USE OF THIS PROCEDURE SmarTrunk Systems, Inc. • 23278 Bernhardt Street Hayward, CA. 94545 • Phone: (510) 887-1950

Fax:(510) 887-4011 • Website: www.selectone.com • E-Mail: technicalsupport@smartrunk.com