



**APPLICATION PARTS
 (not supplied)**

- 1-1K 1/4W resistor
- 1-.22uf-12V capacitor
- 1-Set mounting hardware and wires with pins.

NOTE: All pin numbers noted below are on the Unicall socket on the chassis. Pin 1 is towards the front panel and Pin 10 is toward the center...

SPECIAL NOTICE

WHEN MOUNTING THE TS-32 WITH A 90 DEGREE ANGLE BRACKET AGAINST THE PCB, BE SURE TO USE THE TWO FIBER SPACERS PROVIDED BETWEEN ANGLE BRACKET AND PCB. IF THIS IS NOT DONE, THE BRACKET WILL SHORT OUT FOILS ON THE PCB



Communications Specialists

426 W. Taft Ave., Orange, CA 92667

(714) 998-3021.(California) / (800) 854-0547