

SS - 64 To Icom IC-280

(Switched +V) Direct to the junction of the collector of Q13, and R51 (22K), C65 (220uf) R61 (100 ohm) in PLL U-153

Chassis Ground

Direct to junction of R21 (4.7K) and R20 (4.7K) in PLL U-153 thru a 1 meg resistor

**Optional Use (see SS-64 Instruction Sheet)

Optional Use (see SS-64 Instruction Sheet)

RED 1

BLACK 2

YELLOW 3

ORANGE 4

GREY 5

SS-64 CONNECTOR

Notes

If you want the reverse burst function, follow the directions on the SS-64 instruction sheet to install into your radio's push-to-talk.

** The Orange wire must be grounded to encode tone if jumper JP-1 is out



COMMUNICATIONS SPECIALISTS, INC.

426 WEST TAFT AVENUE • ORANGE, CA 92865-4296

(714) 998-3021 • FAX (714) 974-3420

Entire U.S.A. (800) 854-0547 • FAX (800) 850-0547

<http://www.com-spec.com>