SS - 64 To Kenwood TR-7600/7625 Mobile

To terminal marked "TB" ———————— RED 1

To terminal marked "E" ———————— BLACK 2

To terminal marked "SUB" ———————— YELLOW 3

**Optional Use (see SS-64 Instruction Sheet) ———— ORANGE 4

Optional Use (see SS-64 Instruction Sheet) ———— GREY 5

SS-64 CONNECTOR

Notes

If you want the reverse burst function, follow the directions on the SS-64 instruction sheet to install into your radio's push-to-talk.

** The Orange wire must be grounded to encode tone if jumper JP-1 is out

Photo at right shows mounting location for SS-64 and location of pins for attachment of wires from encoder