



NOTE: Transceiver will encode tone all the time in all tone switch positions. Unit will be in tone receive in the "SQU" switch position and in monitor in all other positions...

APPLICATION PARTS
(not supplied)

- 1- 10K 1/4W resistor
- 1- Silicon diode
- 1- Set wires & hardware

SPECIAL NOTICE

WHEN MOUNTING THE TS-32 WITH A 90 DEGREE ANGLE BRACKET AGAINST THE PCB, BE SURE TO USE THE TWO FIBER SPACERS PROVIDED BETWEEN ANGLE BRACKET AND PCB. IF THIS IS NOT DONE, THE BRACKET WILL SHORT OUT FOILS ON THE PCB



Communications Specialists

426 W. Taft Ave., Orange, CA 92667
(714) 998-3021 (California) / (800) 854-0547