SS - 64 To Azden PCS-4000 Mobile

+12vdc continuous	RED	1	
Chassis Ground -	BLACK	2	TOR
To center tap of deviation pot. VR404, on	YELLOW	3	CONNECTOR
**Optional Use (see SS-64 Instruction Sheet)	ORANGE	4	SS-64 CC
Optional Use (see SS-64 Instruction Sheet)	GREY	5	SS
optional obt (but by or instruction officer)			

Notes

If you want the reverse burst function, follow the directions on the SS-64 instruction sheet to install into your radio's push-to-talk.

** The Orange wire <u>must be grounded</u> to encode tone if jumper JP-1 is out