

## CONNECTION

## **ENCRYPTION UNIT**

## **RADIO**

 $\alpha$ 

(3)	(+) SUPPLY INPUT	RED	J408-6	9V
(9)	(-) SUPPLY INPUT	BLACK	J408-4	GND
(11)	RX AUDIO INPUT	BLUE	J408-11	AUDIO IN
(1)	RX AUDIO OUTPUT	WHT/BLU	J408-12	AUDIO OUT
(12)	TX AUDIO INPUT	GREEN	J410-6	MIC IN
(13)	TX AUDIO OUTPUT	WHT/GRN	J410-7	MIC OUT
(6)	PTT INPUT	YELLOW	J407-8	PTT
(7)	CLEAR/CYPHER	BROWN	J407-4	S301
(4)	BEEP EE CS	WHT/ORG	J408-9	ALARM
(8)	PA ENABLE/CODE #1	BLK/BRN	NO CONNECTION	
(5)	CODE #2	BLK/ORG	NO CONNECTION	
(8)	NOT USED	BLK/YEL	NO CONNECTION	
(2)	RS232	VIOLET	NO CONNECTION	

THIS IS A RECOMMENDED INSTALLATION PROCEDURE FOR SELECTONE EQUIPMENT BASED ON THE BEST INFORMATION AVAILABLE TO US AT THE TIME OF PUBLICATION. SELECTONE ASSUMES NO RESPONSIBILITY FOR THE ACCURACY OF THE INFORMATION OR THE DAMAGE TO EQUIPMENT RESULTING FROM THE USE OF THIS PROCEDURE SELECTONE INC. • 3501 BREAKWATER AVE. HAYWARD, CA. 94545-1610 • (510) 781-0376

(800) 227-0376

• FAX (510) 781-5454 •

E-Mail admin@selectone.com