

CONNECTION

ENCRYPTION UNIT

RADIO

(3)	(+) SUPPLY INPUT	RED	JUNCT. OF R255 AND S209 (CPU UNIT)
(9)	(-) SUPPLY INPUT	BLACK	CN2-1 GND (RF UNIT)
(11)	RX AUDIO INPUT	BLUE	JUNCT. OF R30 AND R31 (RF UNIT)
(1)	RX AUDIO OUTPUT	WHT/BLU	JUNCT. OF R31 AND R32 (RF UNIT)
(12)	TX AUDIO INPUT	GREEN	JUNCT. OF R114 AND R111 (RF UNIT)
(13)	TX AUDIO OUTPUT	WHT/GRN	JUNCT. OF R111 AND C92 (RF UNIT)
(6)	PTT INPUT	YELLOW	J201-2 PTT (CPU UNIT)
(7)	CLEAR/CYPHER	BROWN	JUNCT. OF Q24 AND R102 (RF UNIT)
(4)	SKR BEEP	WHT/ORG	JUNCTI. OF C16 AND C17 (RF UNIT)
(10)	CODE #3	BLK/YEL	USER SELECT (ST-20B ONLY)
(5)	CODE #2	BLK/ORG	USER SELECT (ST-20B ONLY)
(8)	AMP ENABLE	BLK/BRN	N/C
(2)	CODE #1	VIOLET	USER SELECT (ST-20B ONLY)

USER DETERMINE R4, R21, R28 AND R35

REVISED 04-11-00 CPE

THIS IS A RECOMMENDED INSTALLATION PROCEDURE FOR SELECTONE EQUIPMENT BASED ON THE BEST INFORMATION AVAILABLE TO US AT THE TIME OF PUBLICATION. SELECTONE ASSUMES NO RESPONSIBILITY FOR THE ACCURACY OF THE INFORMATION OR THE DAMAGE TO EQUIPMENT RESULTING FROM THE USE OF THIS PROCEDURE SmarTrunk Systems • 23278 Bernhardt St. HAYWARD, CA. 94545 • (510) 887-1950

FAX (510) 887-4011 • E-Mail technical support@smartrunk.com